

The Stump Pod

Thank you for purchasing a Stump Pod.

With a little care you will get many years of dependable service from it.

The bracket is constructed of laser cut heavy gauge 304 stainless steel. The screws are 18-8 grade 300 series. They will outlive a pressure treated post. You can also use a stone or metal post.

Parts list:

- Stump Pod
- #3 square drive, Robertson Bit
- (6) Stainless Steel mounting screws
- ETX models only, (2) 1/4-20 Stainless Steel wing bolts
- This instruction sheet

Installation Instructions:

Installation

- Pick your location
- Position the Stump Pod
- Level the Stump Pod before putting in the screws
- If you are going to Polar Align, you will need to know True North and Latitude
- Mark screw holes
- When installing the screws, drill a slightly oversized pilot hole to avoid breakage in hardwoods such as white oak, teak and maple or in other finished materials such as a deck railing. For Softwood use a 5/32 bit, for hardwoods use a 9/64 drill bit.
- You will need a 1/4 inch hex driver tool to hold the special bit. Do not over tighten the screws when installing them. It is possible to either break the screw or distort the Pod.

Maintenance

- No Routine maintenance, other than cleaning.
- You never need to paint your Stump Pod, but if you want a color to match your locale, the pod can be painted.
- If painting clean and degrease the pod and mask off the stud. You may need a primer or bonding layer. Check the directions for the type of paint you plan to use.

Cautions

- When installing a post, make sure that the location will not be in someone's way.
- Always use eye protection when using tools.

Removal

- Save the special bit, If you every have to remove the pod, you will need the bit and a driver.
- Just remove the screws and it will come off of the railing or stump.

Visit www.Dynapod.com for more information or to order more of our fine products
You can also find information about new products and handy application notes.



FAR Laboratories
P.O. Box 25
South Hadley, MA 01075
800-336-9054, Fax 413-467-9393
Western Massachusetts 413-467-9262